

LOCATION INSTRUCTIONS

Super Swim Pro and Swim Flex Max are usually installed at the shallow end of the pool. However, it may be installed wherever it is best suited for its purpose. If the pool has a flat deck without a raised edge, install Super Swim Pro 4" – 6" back from the edge or lip (fig. 1).

If the pool has a raised edge or lip, we recommend installing your Super Swim Pro 4" – 6" back from the edge or lip (fig 2).

For odd shaped pools install the unit so that the maximum amount of Swimming area is obtained (fig 3).

For above ground pools & wood deck installations; a back plate (wood or metal) is recommended. (fig 4).

NOTE: A minimum of 15 feet of swimming space is needed for all Pools & Spas.

